



g.9

Connector panel

POWER CORD  
NOT INCLUDED


**CONNECTION TO EXTERNAL POWER SUPPLY**  
Connect to external 24Vdc power supply (cable not included)

Observe the polarity indicated on the PLUG

# FREESTYLE Compact Lite CS / PL series

kit for transformation into a walking version Cod. MPZ752E


For external power supply 25Vdc



We thank our users for choosing an OMEGAbalance product, for further information and details visit the website [www.omegabilance.it](http://www.omegabilance.it)

### ⚠ WARNINGS

The manufacturer cannot be held responsible under any circumstances for any damage or loss resulting from improper use of the components.  
Incorrect installation of this product, including inadequate fixing, contrary to what is specified in the instructions, can lead to malfunctions.  
Before carrying out the work, make sure that the power cord is disconnected.  
Perform the operation with an antistatic bracelet.



**CONTENTS OF THE KIT**

- connections board ver. itinerant code:MPZ752F
- 500mm walking battery cable code:MPZ1072
- external plug code:MPM476
- instructions

# OMEGAbalance

RELIABILITY AND DESIGN

Omega Balance Srl  
Single-member company  
Via Bettolino, 1721013 Gallarate (VA) Italy Tel:  
+39 0331 1527940 info@omegabilance.it


[www.omegabilance.it](http://www.omegabilance.it)

MPD520 REV01- APR. 2021

All information contained in this guide may be subject to changes by OMEGAbalance srl without prior notice.

g.1

g.2



**ACCESS TO THE CONNECTIONS CARD**

- (1) Remove the plate and the cross, unscrewing the two Allen screws with a D5 wrench (with "T" handle)
- (2) Remove the top closing frame, secured with the 10 M4x10 screws.

